




PARTS ENCLOSED

- (A) Mounting Screws(2)
- (B) Mounting Plate(1)
- (C) Canopy Screw(4)
- (D) Canopy(1)
- (E) Nut Connector(3)
- (F) Suspension Line(27)
- (G) Glass Shades(27)

KCH3210R-27BS or KCH3210R-27BN

Assembly Instructions

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.
WARNING * SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.**

1. Carefully remove all parts from the box.
2. Determine the required length of the suspension line (F) according to the required height.
3. Loosen mounting bracket from base (B) Side screw (C).
4. Fix the mounting bracket (B) on the outlet box with screw (A).
5. Make sure the power is off.
6. Hold the lamp body and wrap the two safety cables with nipple (E). Press the lamp body (D) on the bracket (B) and secure it with a nut (C).
7. Install the glass lamp shade (G) on the lamp.
8. After installation, switch on the fuse or circuit breaker.

*****Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents*****

