

IMPORTANT SAFETY INSTRUCTIONS:

Please read these instructions carefully before beginning installation.

This fixture must be installed by a qualified electrician familiar with the construction and operation of the product and in accordance with all applicable national and local electrical codes.

Failure to follow these instructions may result in electric shock, fire, personal injury, or damage to the fixture.

WARNING:

1. Turn OFF electrical power at the main circuit breaker before beginning installation.
2. Do not restore power until in0stallation is complete.
3. This fixture is intended for indoor dry locations only, unless otherwise specified.
4. Do not modify the fixture or use replacement parts not supplied by the manufacturer.
5. Keep all combustible materials away from the light source.
6. Do not exceed the electrical rating shown on the fixture label.
7. Ensure the outlet box is securely fastened to the building structure and is suitable for supporting the weight of this fixture.

BEFORE YOU BEGIN

Recommended Installation


For safety and convenience, installation by two people is recommended.

TOOLS REQUIRED (Not Included)

Philips screwdriver, Slotted Screwdriver, Wire Strippers Slip Joint Pliers, Measuring Tape, Chain Pliers,Wire cutters.

CHANDELIER INSTALLATION

A	Wire Connectors	3pcs
B	Green Ground Screw	1pcs
C	Mounting Plate	1pcs
D	Mounting Screws	2pcs
E	Mounting Screws	4pcs
F	Canopy	1pcs
G	Cable (120")	1pcs
H	Acrylic Leaf	22pcs
I	Fixture	1pcs



1. **Unpack the Fixture:** Carefully remove all parts from the carton and place them on a clean, soft surface to prevent damage.
Note: Do not discard the packaging until installation is complete.
2. **Install the Mounting Plate:** Remove the mounting plate (C) from the canopy. Secure the mounting plate to the UL-listed outlet box using the supplied mounting screws (D).
Note: Verify the outlet box is securely attached to the building structure.
3. **Adjust the Suspension Cables:**
 - Determine the desired hanging height.
 - Insert each suspension cable (G) through its cable gripper.
 - Adjust all cables (G) evenly until the fixture hangs level.
 - Once the desired height is reached, confirm each cable is fully locked into its cable gripper.
 - Trim excess cable if necessary, following manufacturer recommendations.
4. **Prepare the Fixture Wires:** Route the fixture wires through the canopy. Trim excess wire, leaving sufficient length to reach the junction box. Strip approximately 5/8 in. (16 mm) of insulation from each conductor.
5. **Make Electrical Connections:** Using the supplied wire connectors (A):
 - Connect the ground wire (green or bare copper) to the building ground.
 - Connect the neutral wire (white or ribbed conductor) to the building neutral (white).
 - Connect the hot wire (black or smooth conductor) to the building hot (black).**NOTE:** Do not reverse the hot and neutral connections. Verify all wire connectors are tight. Carefully tuck all wiring into the junction box.
6. **Install the Canopy (F):**
 - Raise the canopy against the ceiling.
 - Secure it using the canopy mounting screws (E).
 - Ensure no wires are pinched during installation.
7. **Final Fixture Adjustment:** Make necessary Adjustments and verify the following:
 - a. Fixture hangs level
 - b. Suspension cables (G) are equally tensioned
 - c. Cable grippers are fully engaged
 - d. All mounting screws are tight
8. **Install Decorative Components:** Adjust acylic leaf (H) to make all leaf spread evenly
9. **Restore Power:** Restore electrical power. Operate the fixture and verify proper illumination.

MAINTENANCE

1. Disconnect power before cleaning.
2. Clean metal surfaces using a soft dry cloth.
3. Clean glass with a lint-free cloth and non-abrasive glass cleaner.
4. Never use solvents, ammonia, or abrasive cleaners.
5. Periodically inspect all suspension cables and mounting hardware to ensure they remain secure.


IMPORTANT NOTES

1. This fixture is intended for permanent installation only.
2. Do not suspend any additional objects from the fixture.
3. If any component becomes damaged, discontinue use until the fixture has been repaired or replaced with approved parts.
4. Retain these instructions for future reference.

Adjusting the Suspension Cables

CABLE HEIGHT ADJUSTMENT

Each suspension cable passes through a spring-loaded cable gripper located inside the canopy.



Each suspension cable passes through a spring-loaded cable gripper located inside the canopy.

1. To shorten the suspension, simply pull the cable upward through the gripper.
2. To lengthen the suspension, press the release collar on the cable gripper while gently pulling the cable downward.
3. After adjustment, verify that each cable is securely locked by pulling downward firmly on the cable.

Adjust all cables evenly until the fixture hangs level.

INSTALLATION CHECKLIST:

- ☐ Outlet box securely fastened to building structure
- ☐ Mounting plate securely installed
- ☐ Suspension cables properly locked
- ☐ Fixture hanging level
- ☐ Electrical connections completed
- ☐ Ground wire connected
- ☐ Wire connectors secure
- ☐ Wiring safely tucked into junction box
- ☐ Canopy installed flush to ceiling
- ☐ Decorative glass installed
- ☐ Fixture tested successfully