


Parts List

- (A) Wire Connectors ×2
- (B) Screws ×2
- (C) Mounting Bracket ×1
- (D) Ceiling Canopy ×1
- (E) Outer Ring ×1
- (F) Hanging Chain ×1
- (G) Hanging Ring ×1
- (H) Locking Nuts ×2
- (I) Locking Clips ×2
- (J) Fixture Body ×1
- (K) Electrical Wire ×1
- (L) Bare Copper Ground Wire ×1



KPN4100L-7

Assembly Instructions

Recommended: Installation should be performed by a qualified electrician.

Warning: Turn off the main power supply at the fuse box or circuit breaker before starting installation.

1. Carefully remove all parts from the packaging.
2. Install one locking clip (I) and the hanging chain (F). Thread the electrical wire (K) and the bare ground wire (L) through the chain (F), the outer ring (E), and the ceiling canopy (D).
3. Tighten the locking nuts (H) at the appropriate positions.
4. Use screws (B) to attach the mounting bracket (C) to the ceiling junction box.
5. Hang the entire fixture by connecting the locking clip (I) to the hanging ring (G).
6. Connect the electrical wires using wire connectors (A), then tuck the wires into the junction box.
7. Push the ceiling canopy (D) up to cover the mounting bracket (C), and secure it in place with the outer ring (E).
8. Install the bulbs into the sockets.
9. Once installation is complete, restore power by switching on the fuse or circuit breaker.

Cleaning Instructions:

Use only a dry, soft cloth to clean. Do not use abrasive materials or chemical cleaners.