

IMPORTANT SAFETY INSTRUCTIONS

1. These instructions are provided for your safety. It is important that they are read carefully and completely before installing the chandelier.
2. **THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH APPLICABLE INSTALLATION CODES BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HARZARDS INVOLVED.**
3. This fixture has been rated from **2 x 40 watt Max E12** standard bulb(not included).
4. To avoid the risk of fire, do not exceed the recommended wattage.
The light fixture is meant for indoor use. DRY LOCATION ONLY. It must be connected only to 3-wire. Single-phase electrical systems (provided with Ground wire or equivalent protection system).
5. Keep it away from children.

WARNING:

- Turn-off electricity supply at main circuit panel before installing. Do not connect electricity supply until your chandelier is fully assembled and installed.
- To reduce the risk of fire, electrical shock, or personal injury, always turn off the chandelier and allow it to cool. Prior to replacing light bulb. Do not touch bulb when fixture is turned on or look directly at light bulb.
- Keep flammable materials away from light bulb.

PRE-ASSEMBLY:

- Remove all parts and hardware from box along with plastic protective packaging. **Do not** discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- For your safety and convenience, assembly by two people is recommended

ASSEMBLY & INSTALLATION:

1. Carefully remove all parts from the carton and place them on a clean, soft surface to prevent damage.
2. Attach the Tube (L) to the Cluster (K) and secure it to the Bottom Plate (M).
Tighten firmly.
3. Determine the desired hanging height. Use Link Loop (H) to attach one end of Chain (G) to Collar Loop (I) and its another end to Ring (F).
4. Carefully unwind the fixture wires. Trim any excess wire, leaving sufficient length to reach the junction box. Strip approximately 5/8 in. (16 mm) of insulation from each wire end.
5. Remove the mounting plate (B) from the canopy (D) by loosening the mounting screws (C).
6. Secure the mounting plate (B) to the junction box using the provided mounting screws (C).
7. Pull the supply wires out from the junction box and allow them to hang freely.
8. Connect the fixture **ground wire** (green or bare) to the junction box ground wire using a wire connector.
NOTE: Proper grounding is required for safe installation.
9. Connect the fixture **neutral wire (N)** to the supply neutral wire (white) using a wire connector.
10. Connect the fixture **hot wire (L)** to the supply hot wire (black) using a wire connector.
CAUTION: Do not reverse the hot and neutral connections.
11. Ensure all wire connections are secure. Carefully tuck the wires into the junction box.
12. Raise the Canopy (D) to the ceiling and affix it with the ring knob on the chain.
Ensure that it is the chain and not the power cord that is supporting the fixture's weight.
13. Adjust the fixture so it hangs straight and level.
14. Install light bulbs (not included). Do not exceed recommended wattage.

Care Instructions: Clean only with a soft dry cloth or feather duster. Do Not use abrasive or chemical agents

PARTS ENCLOSED:

- (A) Wire Connectors (3 pcs)
(B) Mounting Plate (1 pcs)
(C) Mounting Screw (2 pcs)
(D) Canopy (1 pcs)
(E) Ground Screw (1 pcs)
(F) Ring (1 pcs)
(G) Chain (1 pcs x 120")
(H) Link Loop (2 pcs)
(I) Collar Loop (1 pcs)
(J) Wood Bead Strand (33 pcs)
(K) Cluster (1 pcs)
(L) Tube (1 pcs)
(M) Bottom Plate (1 pcs)

TOOLS REQUIRED (Not Included)

- Philips screwdriver, Slotted Screwdriver, Wire Strippers
- Slip Joint Pliers, Measuring Tape, Chain Pliers
- Wire cutters

Breakdown Diagram 1:

