

IMPORTANT SAFETY INSTRUCTIONS

1. These instructions are provided for your safety. It is important that they are read carefully and completely before installing the chandelier.
2. **THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH APPLICABLE INSTALLATION CODES BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.**
3. This fixture has been rated from **7 x 40 watt Max E12** standard bulb(not included).
4. To avoid the risk of fire, do not exceed the recommended wattage.
The light fixture is meant for indoor use. **DRY LOCATION ONLY.** It must be connected only to 3-wire. Single-phase electrical systems (provided with Ground wire or equivalent protection system).
5. Keep it away from children.

WARNING:

- Turn-off electricity supply at main circuit panel before installing. Do not connect electricity supply until your chandelier is fully assembled and installed.
- To reduce the risk of fire, electrical shock, or personal injury, always turn off the chandelier and allow it to cool. Prior to replacing light bulb. Do not touch bulb when fixture is turned on or look directly at light bulb.
- Keep flammable materials away from light bulb.

PRE-ASSEMBLY:

- Remove all parts and hardware from box along with plastic protective packaging. **Do not** discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- For your safety and convenience, assembly by two people is recommended

ASSEMBLY & INSTALLATION:

1. Carefully remove all parts from the carton and place them on a clean, soft surface.
2. Attach one end of each Rod (#10) to the collar loops on top of the fixture body using the quick link Loops (#11). Tighten the links securely.
3. Attached another end of each Rod to a chain (#9). Tighten the links securely.
4. Determine the desired hanging height and remove excess chain links if necessary.
5. Carefully unwind the fixture wires. Trim excess wire, leaving enough length to reach the junction box. Strip 5/8 in. (16 mm) of insulation from each wire end.
6. Remove the mounting plate (#1) from the canopy (#7) by loosening the two finials (#8)
7. Secure the mounting plate (#1) to the junction box using the provided mounting screws (#5,#6)
8. Gently pull the supply wires from the junction box and allow them to hang.
9. Connect the fixture **GROUND** wire (green or bare) to the junction box ground wire using a wire connector.
NOTE: Proper grounding is required for safe installation.
10. Connect the fixture **NEUTRAL** wire (labeled **N**) to the supply neutral wire (white) using a wire connector.
11. Connect the fixture **HOT** wire (labeled **L**) to the supply hot wire (black) using a wire connector.
CAUTION: Do not reverse the hot and neutral connections.
12. Ensure all wire connections are secure and carefully tuck the wires into the junction box.
13. Slide the canopy up to the ceiling and secure it to the mounting plate using two Canopy Decor Finials (#8)
14. Attach the free end of each chain (#9) to the canopy collar loop using a link Loop (#11). Ensure the chain—not the electrical cord—supports the weight of the fixture.
15. Make final adjustments so the fixture body hangs level.
15. Install the light bulbs (not included). Do not exceed the maximum recommended wattage.

Care Instructions: Clean only with a soft dry cloth or feather duster. Do Not use abrasive or chemical agents

PARTS ENCLOSED:

- (#1) Mounting Plate (1 pieces)
- (#2) Wire Connectors (3 pieces)
- (#3) Ground Screw (1 piece)
- (#5) Concrete Expansive Bolt or Wood Screw (2)
- (#6) Mounting Screw (2)
- (#7) Canopy (1)
- (#8) Canopy Decor Finial (2)
- (#9) Chain (2)
- (#10) Rod (2)
- (#11) Link Loop (6)

(#14) Fixture Body

TOOLS REQUIRED (Not Included)

- Philips screwdriver, Slotted Screwdriver, Wire Strippers
- Slip Joint Pliers, Measuring Tape, Chain Pliers
- Wire cutters

Breakdown Diagram 1:

