

IMPORTANT SAFETY INSTRUCTIONS

1. These instructions are provided for your safety. It is important that they are read carefully and completely before installing the chandelier.
2. **THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH APPLICABLE INSTALLATION CODES BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HARZARDS INVOLVED.**
3. This fixture has been rated from **13 x 40 watt Max E12** standard bulb(not included).
4. To avoid the risk of fire, do not exceed the recommended wattage.
The light fixture is meant for indoor use. **DRY LOCATION ONLY.** It must be connected only to 3-wire. Single-phase electrical systems (provided with Ground wire or equivalent protection system).
5. Keep it away from children.

WARNING:

- Turn-off electricity supply at main circuit panel before installing. Do not connect electricity supply until your chandelier is fully assembled and installed.
- To reduce the risk of fire, electrical shock, or personal injury, always turn off the chandelier and allow it to cool. Prior to replacing light bulb. Do not touch bulb when fixture is turned on or look directly at light bulb.
- **Make sure the junction box can support at least 100 lbs. If not, install the chandelier to a secure building structure that can safely hold its weight.**

PRE-ASSEMBLY:

- Remove all parts and hardware from box along with plastic protective packaging. **Do not** discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- For your safety and convenience, assembly by two people is recommended

ASSEMBLY & INSTALLATION:

1. Carefully remove all parts from the carton and place them on a clean, soft surface.
2. Attached the 4 Branch Chain (H) to the chandelier body. Hook the chains between tiers.
3. Attach one end of the chain (G) to the collar loop on the top end of 4 branch Chain H by using a link. Ensure the link is fully tightened.
4. Determine the desired hanging height. Remove excess chain (G) links if necessary.
5. Carefully unwind the fixture wires. Cut excess wire, leaving enough length to reach the junction box. Separate the wires and strip 5/8 in. (16 mm) of insulation from each wire.
6. Remove the mounting plate (B) from the canopy (D).
7. Secure the mounting plate (B) to the junction box using the mounting screws (C).
8. Gently pull the supply wires from the junction box and allow them to hang.
9. Connect the GROUND wire from the fixture to the GROUND wire from the junction box (green or bare) using wire connector (A).
NOTE: Proper grounding of the fixture is essential.
10. Connect the NEUTRAL fixture wire (labeled as N) to the NEUTRAL supply wire (white) using a wire connector.
11. Connect the HOT fixture wire (Labeled as L)to the HOT supply wire (black) using wire connector (a)
CAUTION: Do not reverse the hot and neutral connections.
12. Ensure all wire connections are secure. Carefully tuck the wires into the junction box.
13. Loosen collar ring and let canopy (D) slip down chain (G) carefully.
14. Slide the canopy (D) upward to the ceiling and secure it to the mounting plate using the collar ring (F)
16. Attach the free end of the chain to the canopy loop using a quick link. Ensure that the chain—not the electrical cord—supports the weight of the fixture.
17. Make final adjustments so all three tiers are level.
18. Hang Iron Rods (I) one by one starting from the bottom tier, until all 618 rods are hung
19. Install the 113 E12 Type B bulbs into the sockets. Do not exceed the maximum recommended wattage.

Care Instructions: Clean only with a soft dry cloth or feather duster. Do not use

PARTS ENCLOSED:

- (A) Wire Connectors (3)
- (B) Mounting Bar (1)
- (C) Mounting screw (2)
- (D) Canopy (1)
- (F) Metal Ring or Canopy Nut Ring
- (G) Chain (1)
- (H) Branch Chain (4)
- (I) Iron Rods (618)

TOOLS REQUIRED (Not Included)

- Philips screwdriver, Slotted Screwdriver, Wire Strippers
- Slip Joint Pliers, Measuring Tape, Chain Pliers
- Wire cutters

Breakdown Diagram 1:

